






Throttle with Cruise switch:





1	GND	GND
2	Cruise Signal	CR
3	NA	
4	Throttle 5V	+5V
5	Throttle Signal	SP
6	Throttle Ground	GND

3 Speed Switch:





1	X1
2	X2
3	GND

E-Brake:




1	Ebrake Signal	EBS-
2	GND	GND

Power Switch (Low Current, fitted to Adaptor Cable):



1	Positive Feed	Vcc
2	Positive Supply	Vcc-L

CA Connector:



1	Battery Voltage	Vcc-L
2	GND	Shunt +ve
3	Shunt -ve	Shunt -ve
4	Shunt +ve	Shunt +ve
5	Speed Signal	HE (fit QSA/RSA1)
6	Throttle signal	Throttle via IN4001